



# Double Pedestal Broadcaster

Installation Instructions for

Double Pedestal Broadcaster for Model P-15 and P-17

## Tools Needed

- Tape Measure
- Safety Glasses
- Safety Gloves
- Screwdriver
- Drill
- Level

## Hardware Needed

- All parts included

## Installation

1. Slide top hinge (A) down and bottom hinge (B) up.
2. Slide left hinges (C) to right and right hinges (D) to left.
3. Remove back panel (E).
4. Insert art, menu, poster or sign (F).
5. Reattach back panel.
6. Slide top hinge (A) up and bottom hinge (B) down.
7. Slide left hinges (C) to left and right hinges (D) to right. Lock back into place.

