



Installation Instructions for
The Rocker™ 3, 4, 5, 6, 7, 8

AARGO
PRODUCTS INC.

Tools Needed


- Tape Measure
- Safety Glasses
- Safety Gloves
- Screwdriver
- Drill
- Level

Hardware Needed

- All parts included

Installation

1. Remove all parts from box.
2. Attach feet (L) to uprights (A).
3. Remove screws (H) and washer (I) from weighted spanner tubes (B).
4. Attach pre-assembled weighted spanner tubes (B) into upright (A) left side first, attach screws (H) and large metal washer (I), insert spanner tube cap (F) Insert tighten, then same on right side.
5. Measure 12 inches (30cm) down from top of sign face (J) and mark edge. This is where the cross rod (C) will slide through sign.
6. Assemble cross rod (C), U channel (E), knob bushing (G) and knob (D) on left side and tighten, then same on right side.
7. Enjoy your new Arco Rocker™.



* **SALE Special 1234567890%**

Parts Included

ROC-3, ROC-5, ROC-7

PART LIST	QUANTITY	DESCRIPTION
A	2	Uprights
B	2	Bottom Spanner Tubes
C	1	10-32 Threaded Rod
D	2	Knob
E	2	U Channel
F	4	Spanner Tube Caps
G	2	Knob Bushing
H	4	Large Screws
I	4	Large Metal Washer
J	1	Letter Board Unframed
K	1	Letter Set (354 Pieces)
L	4	Feet (2 Pieces)

ROC-4, ROC-6, ROC-8

PART LIST	QUANTITY	DESCRIPTION
A	2	Uprights
B	2	Bottom Spanner Tubes
C	1	10-32 Threaded Rod
D	2	Knob
E	2	U Channel
F	4	Spanner Tube Caps
G	2	Knob Bushing
H	4	Large Screws
I	4	Large Metal Washer
J	1	Letter Board Unframed
K	1	Letter Set (354 Pieces)
L	4	Feet (2 Pieces)
*	1	8" Deluxe Letter Set